


**BOSCH**

HEE6923/01-D1, weiss
 HEE6923DK/01-DK1, weiss
 HEE6924NN/01-N1, weiss
 HEE6923/02-D2, weiss

HERDE
 Einbau-Herde



Ident - Nummern - Konstante
 3740

Gebrauchsanweisung

51 5789
 (D,F,GB,NL)
 51 5062
 (N,DK)
 Tips und Rezepte
 51 4782
 (D)
 Montageanleitung
 51 5519
 (D,F,GB,I,NL,DK)
 51 4502
 (S,N,SF)
 Bratzeit-Automatik-
 Wählscheibe
 51 3359
 (D,F,GB,I,NL)
 Bratzeit-Automatik-
 Faltblatt
 51 3533
 (S,N,SF,DK)

1) 05 6747
 2) 05 6731
 3) 05 9875


Zubehör:

HEZ 15BB
 Alu-Backblech
 HEZ 22BB
 Backblech emailliert
 HEZ 16 BP
 Bratpfanne
 HEZ 16KP
 Universalpfanne
 HEZ 10SP
 Spritzschutzpfanne
 HMZ 211 GB
 Glasbräter

**BOSCH**

HEE6923/01-D1, weiss
 HEE6923DK/01-DK1, weiss
 HEE6924NN/01-N1, weiss
 HEE6923/02-D2, weiss

HERDE
 Einbau-Herde



Ident - Nummern - Konstante
 3740


- 1) 02 9754
- 2) 03 0114
- 3) 02 6689
- 4) 05 6948
- 5) 02 1753
- 6) 06 5483
- D1, D2, DK1
- 05 9710
- N1
- 7) 05 6951
- 8) 03 0092
- 30 Ohm
- 9) 05 9712
- 750 Ohm
- 10) 04 3326
- 500 Ohm
- 11) 27 1572
- rechts
- 27 1573
- links
- 12) 08 8413
- 13) 08 8410
- 14) 02 6589
- 15) 11 9303
- 16) 11 3908

**BOSCH**

HEE6923/01-D1, weiss
 HEE6923DK/01-DK1, weiss
 HEE6924NN/01-N1, weiss
 HEE6923/02-D2, weiss

HERDE
 Einbau-Herde

Ident - Nummern - Konstante
 3740



**BOSCH**

HEE6923/01-D1, weiss
HEE6923DK/01-DK1, weiss
HEE6924NN/01-N1, weiss
HEE6923/02-D2, weiss

HERDE
Einbau-Herde

Ident – Nummern – Konstante
3740

