


**BOSCH**

WFK4410-WFK4410FG/03-FG1
 WFK4410-WFK4410SI/03-SI1
 WFK4410-WFK4410FG/04-FG2
 WFK4410-WFK4410SI/04-SI2

WASCHGERÄTE
 Waschvollautomaten



Ident - Nummern - Konstante
 3740

- 1) 08 8738
 (D,I)
 08 8734
 (NL,F)
 08 8736
 (E,GB)
 08 8735
 (S,DK)

Gebrauchsanweisungen:

- 51 3566
 (D,I,S,N,SF)
 51 3568
 (NL,F,E,GB)

Programmtabellen:

- 51 3552
 (D)


- 51 3553
 (I,S,N,SF)

- 51 3555
 (NL,F,E,GB)

Aufstellanweisungen:

- 51 3556
 (D,I,S,N,SF)


- 51 3558
 (NL,F,E,GB)



**BOSCH**

WFK4410-WFK4410FG/03-FG1
 WFK4410-WFK4410SI/03-SI1
 WFK4410-WFK4410FG/04-FG2
 WFK4410-WFK4410SI/04-SI2

WASCHGERÄTE
 Waschvollautomaten



Ident – Nummern – Konstante
 3740


- 1) 03 0055
LINKS
03 0054
RECHTS
- 2) 03 0052
RECHTS
03 0051
LINKS

**BOSCH**

WFK4410-WFK4410FG/03-FG1
 WFK4410-WFK4410SI/03-SI1
 WFK4410-WFK4410FG/04-FG2
 WFK4410-WFK4410SI/04-SI2

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740



- 1) 05 6766
 FG1, SI1
 05 8436
 FG2, SI2
 2) 27 1717
 15 5272
 Triac-Motorleistung

**BOSCH**

WFK4410-WFK4410FG/03-FG1
WFK4410-WFK4410SI/03-SI1
WFK4410-WFK4410FG/04-FG2
WFK4410-WFK4410SI/04-SI2

WASCHGERÄTE
Waschvollautomaten

Ident - Nummern - Konstante
3740

