




51 5100
Gebrauchsanweisung
(D)

51 1936
 Tips und Rezepte
 (D)


51 0833
Bratzeit-Aut.-Scheibe
(D,GB,F,I,NL)

- 1) 05 3176
- 2) 02 1947
- 3) 02 9368
- 4) 01 8981
- 5) 05 1477
- 6) 08 3566


Zubehör:


Alu-Backblech
CZ 20170



Bratrost
CZ 20180



1) 02 2695







1) 09 5120
Set

