








51 1221
Aufstellanweisung
fünfsprachig
(D,F,I,NL,GB,E)

51 1238
Gebrauchsanweisung
fünfsprachig
(D,F,I,NL,GB,E)

51 1223
Programmtabelle
fünfsprachig
(D,F,I,NL,GB,E)







1) 07 3594/24
D1, N1, SF1
1500 W
07 3592/25
N1, SF1
950 W

2) 14 0159/44*
bis FD 6510
D1, N1, SF1
14 0373/44
ab FD 6511
D1
14 0374/44
ab FD 6511
N1, SF1

*05 0117/02
bis FD 6409
mitbestellen

