


**BOSCH**

HES6201/01-D1, weiss
HES6201/02-D2, weiss

HERDE
Stand-Herde



Ident – Nummern – Konstante
3740

Gebrauchsanweisung
51 4808
(D,F,GB,I,NL)
Tips und Rezepte
51 2091
(D)

Zubehör:

HEZ 13BB
Alu-Backblech

HEZ 20BB
Backblech emailliert

HEZ 15BP
Bratpfanne

HEZ 15KP
Universalpfanne

HEZ 10SP
Spritzschutzpfanne

HMZ 21GB
Glasbräter




BOSCH

HES6201/01-D1, weiss
HES6201/02-D2, weiss

HERDE
Stand-Herde

Ident – Nummern – Konstante
3740




**BOSCH**

HES6201/01-D1, weiss
HES6201/02-D2, weiss

HERDE
Stand-Herde

Ident – Nummern – Konstante
3740




- 1) 02 8875
- 2) 02 8876
- 3) 02 8578
- 4) 05 6112
- 5) 05 6101
- 6) 02 8634
- 7) 02 8633



BOSCH

HES6201/01-D1, weiss
HES6201/02-D2, weiss

HERDE
Stand-Herde



Ident - Nummern - Konstante
3740



BOSCH

HES6201/01-D1, weiss
HES6201/02-D2, weiss

HERDE
Stand-Herde

Ident - Nummern - Konstante
3740

