


**BOSCH**

HMG2204/01-D1, weiss
 HMG220463/01-B1, weiss
 HMG220467/01-NL1, weiss


HMG220469/01-F1
 HMG220489/01-GB1

HERDE
 Mikrowellenherde

Ident-Nummern-Konstante
 3740



51 3312
 Gebrauchsanweisung
 (D,GB,F,I,NL)
 Kochbuch + MW
 51 2801
 (D)
 51 2803
 (F)
 51 3232
 (NL)
 51 2802
 GB1
 51 3684
 Kurzanleitung
 (D)



- 1) 11 9326
- 2) 11 6684
- 3) 11 4538
Backblech
02 8732
Anschlagteil
- 4) Seitenblech
kompl.
27 0006
links
27 2084
rechts
- 5) 03 1615
rechts
03 1616
links

**BOSCH**

HMG2204/01-D1, weiss
HMG220463/01-B1, weiss
HMG220467/01-NL1, weiss


HMG220469/01-F1
HMG220489/01-GB1

HERDE
Mikrowellenherde

Ident-Nummern-Konstante
3740

1) 02 7045

2) 02 7044



**BOSCH**

HMG2204/01-D1, weiss
HMG220463/01-B1, weiss
HMG220467/01-NL1, weiss

HMG220469/01-F1
HMG220489/01-GB1

HERDE
Mikrowellenherde

Ident-Nummern-Konstante
3740

