


**BOSCH**

HMG2204/03-D1, weiss
 HMG220463/03-B1, weiss
 HMG220467/03-NL1, weiss
 HMG220469/03-F1

HMG220489/03-GB

HERDE
 Mikrowellenherde

Ident – Nummern – Konstante
 3740



51 3312
Gebrauchsanweisung
(D,GB,F,I,NL)

Kochbuch + MW

51 2801

(D)

51 2803

(F)

51 3232

(NL)

51 2802

GB1

51 3684

Kurzanleitung

(D)


**BOSCH**

HMG2204/03-D1, weiss
 HMG220463/03-B1, weiss
 HMG220467/03-NL1, weiss
 HMG220469/03-F1

HMG220489/03-GB

HERDE
 Mikrowellenherde

Ident – Nummern – Konstante
 3740




- 1) 11 9326
- 2) 11 6684
- 3) 11 4538
Backblech
02 8732
Anschlagteil
- 4) Seltenblech
kompl.
27 0006
links
27 2084
rechts
- 5) 03 1615
rechts
03 1616
links

**BOSCH**

HMG2204/03-D1, weiss
HMG220463/03-B1, weiss
HMG220467/03-NL1, weiss
HMG220469/03-F1

HMG220489/03-GB

HERDE
Mikrowellenherde



Ident - Nummern - Konstante
3740

- 1) 02 7045
- 2) 02 7044

**BOSCH**

HMG2204/03-D1, weiss
HMG220463/03-B1, weiss
HMG220467/03-NL1, weiss
HMG220469/03-F1

HMG220489/03-GB

HERDE
Mikrowellenherde

Ident - Nummern - Konstante
3740

