







Gebrauchsanweisungen
 51 1958
 (D, GB, F, I, NL)
 51 1959
 (D, F, I, DK, S)
 51 1960
 (SF, N)

Aufstellanweisungen
 51 1961
 (D, GB, F, I, NL)
 513114
 (D, F, I, Dk, S)
 513115
 (SF, N)





- 1) 053943
- 2) 053944
- 3) 054942
Set
links und rechts



- 1) 08 7191
D1,SF1,N1
08 5462
CH1,DK1,S1
2) 02 1439