

FM700Q1 FM702N1
 FM700Q4 FM702N4
 FM700N1 FM710Q1
 FM700N4 FM710Q6
 FM702Q1
 FM702Q4


VIDEOGERÄTE
 Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		ZUBEHÖR	ACCESSORIES
	75 8017	Fernbedienung FM710Q1/Q6	Remote Control
	75 7633	Fernbedienung FM700Q1/Q4	
	75 8017	Fernbedienung FM700N1/N4	
	75 7632	Fernbedienung FM702Q1/Q4	
	75 8016	Fernbedienung FM702N1/N4	
	79 0536	Batteriefachklappe für Fernbedienung	FLAP f. Remote Control
	75 6840	Antennenkabel	RF-cable
		ELEKTRISCHE TEILE	ELECTRICAL PARTS PIECES ELECTRIQUE
DG901	75 7630	Anzeige FLD	Display
RC901	75 7629	IR-Empfänger	IR-Receiver
			
D2	73 1459	1SS131	
D3	73 1459	1SS131	
D101	79 0491	2A072A	
D102	79 0491	2A072A	
D103	79 0491	2A072A	
D104	79 0491	2A072A	
D105	79 0491	2A072A	
D106	79 0491	2A072A	
D107	79 0491	2A072A	
D108	79 0491	2A072A	
D109	70 9740	1N4003	
D110	70 9740	1N4003	
D111	73 1619	1S2471	
D112	70 9740	1N4003	
D201	73 1459	1SS131	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
D202	73 1459	1SS131	
D203	73 1265	1SR35-200T	
D301	73 1459	1SS131	
D302	73 1459	1SS131	
D304	73 1459	1SS131	
D305	73 1459	1SS131	
D306	73 1459	1SS131	
D401	73 1459	1SS131	
D503	73 1265	1SR35-200T	
D504	73 1265	1SR35-200T	
D505	73 1459	1SS131	
D506	73 1459	1SS131	
D507	73 1459	1SS131	
D508	73 1459	1SS131	
D509	73 1459	1SS131	
D510	73 1459	1SS131	
D901	73 1459	1SS131	
D902	73 1459	1SS131	
D903	73 1459	1SS131	
D904	73 1459	1SS131	
D905	73 1459	1SS131	
D906	73 1459	1SS131	
D907	73 1459	1SS131	
D908	73 1459	1SS131	
D909	73 1459	1SS131	
D910	73 1459	1SS131	
D911	73 1459	1SS131	
D912	73 1459	1SS131	
D913	73 1459	1SS131	
D914	73 1459	1SS131	
D915	73 1459	1SS131	
D923	73 1459	1SS131	
ZD101	73 7478	MTZ8.2B	
ZD102	79 0505	33B	
ZD103	79 0505	33B	
ZD104	73 2338	UZ-13BL	
ZD105	73 2338	UZ-13BL	
ZD303	72 9088	MTZ10B	
ZD501	73 2339	UZ10BSB	
ZD502	73 7544	UZ8.2BSC	

FM700Q1	FM702N1
FM700Q4	FM702N4
FM700N1	FM710Q1
FM700N4	FM710Q6
FM702Q1	
FM702Q4	

VIDEOGERÄTE
Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo



* nur kpl. wechseln
 change cpl. only

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		Gebrauchsanweisung	instruction manual
	53 0803	FM700N1/N4	
	53 0780	FM700Q1/Q4	
	53 0781	FM702Q1/Q4	
	53 0804	FM702N1/N4	
	53 0862	FM710Q1/Q6	
		Service-Druckschrift	service booklet brochure service
	53 5442	Schaltplan	circuit diagram schéma de commutation
		Abgleich	alignment
	53 5443	Elektrisch	alignement
	53 5444	Mechanisch	
	53 5442	Ergänzung zum Schaltplan	supplement to schematic diagram
		Service Mittel	service tools
	34 0114	Drehmomentmesser	torgue gauge
	34 0119	Höhenmeßuhr	hight gauge
	34 0105	Cassettenlehre	tape gauge
	34 0307	Wickeltellerlehre	reel table fixing
	34 0101	Exentrik/ 3 mm	exentrik/ 3 mm
	34 0163	Multi Testcassette	multi tape
	34 0156	Bandzugcassette 60/300 g	tension tape
	34 0219	Bandzugcassette 800 g	tension tape

FM700Q1 FM702N1
 FM700Q4 FM702N4
 FM700N1 FM710Q1
 FM700N4 FM710Q6
 FM702Q1
 FM702Q4

VIDEOGERÄTE
 Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC1	79 0492	LA7376	
IC101	79 0096	MC7806CT	
IC102	79 0096	MC7806CT	
IC201	79 0493	BU2799S	
IC301	73 1107	LA7016	
IC302	73 1107	LA7016	
IC303	73 0303	BA7025L	
IC304	79 0494	HA118135NT	
IC305	79 0099	MSM7401RS	
IC401	73 1107	LA7016	
IC402	79 0230	LA7295	
IC501	79 0100	GL7445	
IC502	79 0544	HD40747719FS	
IC502	79 2883	HD404719A10FS	
IC502	79 1652	HD404719A15FS	
IC503	79 0101	PST-523G	
IC701	79 0496	LA7545	
IC7A1	79 0495	SAA4700 (VPS)	
IC901	79 0497	SDA2516	
			
Q1	79 0500	KTC3199-GR	
Q2	79 0500	KTC3199-GR	
Q3	79 0500	KTC3199-GR	
Q4	79 0501	KTA1267-GR	
Q5	79 0500	KTC3199-GR	
Q6	79 0500	KTC3199-GR	
Q7	79 0501	KTA1267-GR	
Q8	79 0108	KN1204	
Q101	79 0502	KTD1414	
Q102	79 0502	KTD1414	
Q103	79 0107	KN2203	
Q104	73 3733	KTA966-Y	
Q105	73 2181	DTC124ES	
Q201	79 0108	KN1204	
Q202	73 8611	KTC1815GR	
Q301	79 0502	KTA1267GR	
Q303	79 0500	KTC3199-GR	
Q304	79 0500	KTC3199-GR	
Q305	79 0500	KTC3199-GR	

FM700Q1 FM702N1
 FM700Q4 FM702N4
 FM700N1 FM710Q1
 FM700N4 FM710Q6
 FM702Q1
 FM702Q4


VIDEOGERÄTE
 Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
Q306	73 9131	KTC2236A	
Q307	79 0501	KTA1267-GR	
Q308	79 0108	KN1204	
Q309	79 0108	KN1204	
Q310	79 0500	KTC3199-GR	
Q311	79 0108	KN1204	
Q313	73 9131	KTC2236AY	
Q314	79 0108	KN1204	
Q315	79 0108	KN1204	
Q317	79 0108	KN1204	
Q401	73 9131	KTC2236	
Q402	79 0108	KN1204	
Q403	79 0107	KN2203	
Q404	79 0500	KTC3199-GR	
Q501	79 0108	KN1204	
Q502	79 0108	KN1204	
Q503	79 0108	KN1204	
Q504	79 0108	KN1204	
Q505	73 8604	KTC1815-Y	
Q506	73 3733	KTA966-Y	
Q507	79 0108	KN1204	
Q508	79 0108	KN1204	
Q701	79 0503	KTC3388A-Y	
Q702	79 0500	KTC3199-GR	
Q703	79 0500	KTC3199-GR	
Q704	79 0500	KTC3199-GR	
Q705	79 0500	KTC3199-GR	
Q707	79 0500	KTC3199-GR	
Q708	79 0500	KTC3199-GR	
Q709	79 0109	KN1203	
Q710	79 0109	KN1203	
Q711	79 0109	KN1203	
Q712	73 3733	KTA966-Y	
			
X301	79 0506	4.433619 MHz	
X302	79 0507	SFE4.25MBF	
X501	73 2454	32.768 KHz	
X502	79 0508	Resonator	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
DL301	79 0543	 Verzögerungsleitung	
T401	79 0498	  Osc. 70 KHz	
FL301	79 2963	12.3 MHz Trap	
FL302	79 1968	3 MHz (LPF)	
FL303	79 0509	4.43 MHz	
FL304	79 2848	1.5 MHz (LPF)	
Z701	79 0510	SAWOFW	
Z702	79 0541	TPS5.5MB	
Z704	79 0542	CBA5.5ME21	
T701	79 0499	PIF(DIS)	
C101	79 0553	 0.0047 μ F/400V	
C102	79 0554	0.0047 μ F/400V	
C119	79 0555	4700 μ F/35V	
F101	70 0620	 T500mA, 250V	
F102	70 4628	T2A, 250V	
F103	70 0604	T1,25A, 250V	
PT101	75 7623	 Netztrafo	
SWD01	79 0526	 Mode	
SWD02	79 3248	Tape IN/OUT	
SW901	79 0504	UPT-1105AP	
SW902	79 0504	UPT-1105AP	
SW903	79 0504	UPT-1105AP	
SW904	79 0504	UPT-1105AP	


FM700Q1 FM702N1
 FM700Q4 FM702N4
 FM700N1 FM710Q1
 FM700N4 FM710Q6
 FM702Q1
 FM702Q4

VIDEOGERÄTE
 Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
SW905	79 0504	UPT-1105AP	
SW906	79 0504	UPT-1105AP	
SW907	79 0504	UPT-1105AP	
SW908	79 0504	UPT-1105AP	
SW909	79 0504	UPT-1105AP	
SW910	79 0504	UPT-1105AP	
SW911	79 0504	UPT-1105AP	
SW912	79 0504	UPT-1105AP	
SW913	79 0504	UPT-1105AP	
SW914	79 0504	UPT-1105AP	
SW915	79 0504	UPT-1105AP	
SW916	79 0504	UPT-1105AP	
SW917	79 0504	UPT-1105AP	
SW918	79 0504	UPT-1105AP	
SW919	79 0504	UPT-1105AP	
SW920	79 0504	UPT-1105AP	
			
VR201	79 0545		
VR301	73 1446	1 KOhm	
VR302	73 4377	15 KOhm	
VR303	73 1450	10 KOhm	
VR304	73 1450	10 KOhm	
VR305	73 6339	33 KOhm	
VR306	73 1446	1 KOhm	
VR307	73 1450	10 KOhm	
VR310	73 1450	10 KOhm	
VR401	79 0546		
VR402	79 0547		
VR701	79 0548		
VR901	79 0549		

FM700Q1	FM702N1
FM700Q4	FM702N4
FM700N1	FM710Q1
FM700N4	FM710Q6
FM702Q1	
FM702Q4	


VIDEOGERÄTE
Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo



A= FM700Q1/Q4
 B= FM702Q1/Q4
 C= FM700N1/N4
 D= FM702N1/N4
 E= FM710Q1/Q6

FM700Q1 FM702N1
FM700Q4 FM702N4
FM700N1 FM710Q1
FM700N4 FM710Q6
FM702Q1
FM702Q4


VIDEOGERÄTE
Video-Cass-Recorder
Video Equipments
Video Cartride Recorder
Equipments Video
Enregistreur Cassette Vidéo



FM700Q1
FM700Q4
FM700N1
FM700N4
FM702Q1
FM702Q4


FM702N1
FM702N4
FM710Q1
FM710Q6

VIDEOGERÄTE
Video-Cass-Recorder
Video Equipments
Video Cartride Recorder
Equipments Video
Enregistreur Cassette Vidéo



FM700Q1	FM702N1
FM700Q4	FM702N4
FM700N1	FM710Q1
FM700N4	FM710Q6
FM702Q1	
FM702Q4	

VIDEOGERÄTE
Video-Cass-Recorder
 Video Equipments
 Video Cartridge Recorder
 Equipments Video
 Enregistreur Cassette Vidéo



A= FM700/702Q1/Q4
 B= FM700/702N1/N4
 C= FM710Q1/Q6