







Gebrauchsanweisung
52 6399
(DE,GB,FR,IT,NL
PT,ES)

- 1) 17 2761
- 2) 17 2762
- 3) 17 2579
- 4) 17 2259
- 5) 26 6670
- 6) 17 2574
- 7) 17 2575



- 1) 17 2274
- 2) 06 0115
- 3) 06 0083
- 4) 35 9220
- 5) 35 9217
- 6) 35 9219





TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor		ASPERA		
Typ/Type/Tipo		NBT 1118Y		
Förderleistung/Delivery/Debit/Aspiración l/h		2574		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A		–		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		11.0		
Hi/aux.		16.4		
Klappe Therm./Thermostat/Termostat				
Typ/Type/Tipo				
Reglerstellung/Position/Conexión				
Schaltwerte/Switching values/		..ein/conex. °C		
Valeurs de commutation/Desconex.		..aus"/descon.		
(..abtaven' od)		..alarm'		
Füllmenge/Fill. quantily/Charge/Carga R600		g	45	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.		W	150	
Heizung/Heater/Chauflage/Resistenc.descong.			Verdampfer	Ablaufrinne
Widerstand/Resistance/Resistencia		KΩ	0.38	1.4
Leistung/Power/Puissance/Potencia		W	145/230	37.5/230
				Luftkanal
				13.49
				4/230
Ventilador/Blower/Ventilateur/Ventilador			Verdichter	Verdampfer
Widerstand/Resistance/Resistencia		KΩ	0.61	0.41