

Pos. Item Pos.	Ident-Nr. Idenr-No N° d'ident	Bezeichnung	Designation Désignation
		Gehäuseteile	
	75 6651	Gehäusefront	front cabinet/face avant du boitier
	75 6652	Gehäuserückteil	rear cabinet/ebenisterie-partie derr
	73 8142	Batteriefachdeckel	battery lid/couvercle p. boitier de batteri
	73 8137	Fenster für LCD	window f. LCD/hublot p. LCD
		Elektrische Teile	
LCD101	73 8135	Display, AE9068	Display
SP1	73 8134	Lautsprecher 4 Ohm	speaker/haut parleur
	75 6650	Kopfhörer 32 Ohm	head phone/recepteur serre tete
X101	73 8145	Quarz, 75 kHz	quartz
			
S1	73 8132	f.Lautsprecher	f. speaker/p. haut parleur
S101	73 8130	Netz	power/secteur
S102	73 8131	Lock/Release	
			
VR1	73 8133	f. Lautstärke	f. volume/volume
			
Q1	73 7668	2SK212E	
Q2	73 8129	2SA608F-SP	
Q3	73 8128	2SC1623(L6)	
Q4	73 8128	2SC1623(L6)	
Q101	73 8127	2SA812(M6)	
Q102	73 8128	2SC1623(L6)	
Q103	73 8128	2SC1623(L6)	
Q104	73 8128	2SC1623(L6)	
Q105	73 8128	2SC1623 (L6)	

Pos. Item Pos.	Ident-Nr. Idenr-No N° d'ident	Bezeichnung	Designation Désignation
Q106 Q107 Q108	73 8127 73 8127 73 5383	 2SA812(M6) 2SA812(M6) 2SB815 B6/B7	
D1 D2 D3 D4 D5 D101 D102 D103 D104	73 2336 73 2336 73 4037 73 4037 73 7658 73 8143 73 8143 73 8144 73 8143	 SVC201SP SVC210SP KV1236Z3-2/3/4 KV1236Z3-2/3/4 1N4148T BAS16 BAS16 1S2837 BAS16	
IC1 IC2 IC3 IC4 IC101 IC102	73 8122 73 8123 73 8124 73 8125 73 8121 73 8126	 TA8158F TA8132F AN7118S TA8126F TC9308AF010 TD6134AF	
JK1	73 8136	Kopfhörerbuchse	headphone socket/jack de récepteur serre-tete
	43 0155	Austauschgerät	exchange apparatus appareil d'échange
	53 0624	Gebrauchsanleitung	instruction manual instruction d'emploi
	53 5357	Service-Anleitung	service booklet brochure service