


Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
	53 1154	Gebrauchsanweisung D-GB-F-E	Operation Instructions
	53 1155	Gebrauchsanweisung I-NL-S-DK	Operation Instructions
	53 5608	Service Manual	
	53 5687	Ergänzung zum Basis Service Manual	Supplement to Basis Service Manual
	53 5613	DL-Mechanik	
	53 5609	Schaltpläne und Platinen	Schematic diagram
		Zubehör	
	73 8884	Trageband	Shoulderstrap
	75 1529	AC-Verbindungskabel	AC-cable
	79 4240	DC-Verbindungskabel	DC-cable
	75 2521	AV-Verbindungskabel, cinch	AV-cable, cinch
	79 4474	Cinch-Skart Adapter	cinch-scart adaptor
	79 4021	Akku 4,8V/1 Ah	FZ168G4
	75 8918	Akku 4,8V/2,4 Ah	FZ169G4
	75 7000	VHS-Cassettenadapter	FZ163G4
	73 8076	S-Verbindungskabel	s-cable
	78 3177	AC-Adapter	FZ157G4

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		FUNKTIONSEINHEITEN	
	75 9413	Grundplatine, Camera	Camera main P.C.B.
	79 4665	Linse, flex	Lens flex P.C.B.
	79 5485	Mikrofon	Microphone P.C.B.
	79 5487	Manual Fokus	Front operation
	79 5488	Start-Stop	Start-Stop P.C.B.
	79 5489	Sucher	E.V.F. P.C.B
	79 5606	CCD	CCD flex P.C.B.
	79 5607	AC-Buchsen	AC jack P.C.B.
		DIVERSE BAUTEILE	
J1602	79 3959	Akkuaufnahme	Battery catcher
J1601	79 3960	DC-Buchse	DC jack
Z1601	79 3841	VL2330/1HF	Lithium Battery
TH701	79 3963	Thermistor	
	73 9873	0N1004-R	Photosensor
R1601	79 2710	0.025 Ohm	
	79 3339	AV-Buchsenplatte	AV-Jackplate



Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
C861	79 5246	0,01 µF, 50 V	
C1040	79 5246	0,01 µF, 50 V	
C1041	79 5246	0,01 µF, 50 V	
C2012	79 5246	0,01 µF, 50 V	
C2013	79 5246	0,01 µF, 50 V	
C2020	79 5246	0,01 µF, 50 V	
C2021	79 5246	0,01 µF, 50 V	
C2022	79 5246	0,01 µF, 50 V	
C2070	79 5246	0,01 µF, 50 V	
C6005	79 5246	0,01 µF, 50 V	
			
IC51	79 5480	TA75S393F85L	
IC201	79 5474	MN5224	
IC202	79 5609	MB87882PFV	
IC203	79 5478	NN2037FAQ	
IC204	79 5059	TA75W01FU	
IC205	79 5477	NJM2904V	
IC301	79 5483	TC9084F	
IC302	79 5048	M62366GP	
IC303	79 5470	M62367GP	
IC305	79 3091	CXD2300Q	
IC306	79 5610	SC7S04F	
IC307	79 0770	TC4W53F	
IC308	79 5482	TC7S14FU	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC705	79 5466	BA6950FS	
IC706	79 5476	NJM2115V	
IC707	73 9720	LM324DB	
IC708	79 4416	TB6512AF	
IC710	79 5473	MN1882421M3E	
IC711	79 5059	TA75W01FU	
IC801	79 4406	AN2516S	
IC1001	79 3803	BA9706K	
IC2001	79 5481	TB6518F	
IC2002	79 0798	UN224	
IC2003	79 0798	UN224	
IC3001	79 5469	M52381FP	
IC4001	79 5467	BA7758FS	
IC5001	79 5465	AN3355FHP	
IC5501	79 5484	TL8850F	
IC6001	79 5475	MN6755486M4E	
IC6002	79 5472	MM1273XFF	
IC6003	79 5468	BU6140FV	
IC6004	79 5041	AK6440HF	
IC6005	79 3089	BA6289F	
IC6006	79 4415	TA75W393FU	
IC6007	79 0770	TC4W53F	
IC6008	79 0771	TC7W04F	
IC6501	79 5611	UPD4538BG	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
SW501	79 2426	Autofocus	
SW502	79 2426	Eject	
SW892	79 5617	Eject	
S6702	79 5616	Camera Power	
			
T801	79 4670	Zeilentransformator	flyback
T1001	79 5619	Netzteil	Power section
T1002	79 4427	Netzteil	Power section
T4001	79 4659	Löschoszillator	Erase osc.
			
X301	79 3345	19.3125 MHz	
X701	79 0824	12 MHz	
X6001	79 4295	16.00 MHz	
X6002	79 4671	32.768 KHz	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		MESSWERKZEUGE	
	34 0217	Conv. Filter	C2
	34 0216	Conv. Filter	C12
	34 0290	EVR Abgleichcomputer	EVR Fixture
	34 0214	H-Position Abgleich	H-Position Adjustment
	79 5613	ROM28	ROM
	34 0260	VHS-C Abgleichcassette	VHS-C Alignment Tape
		ADAPTERKABEL	
	34 0189	EVR Verbindungskabel	EVR Connection cable 5Pin
	34 0199	Messadapter	Measurement cable 24Pin
	34 0368	Flexkabel	Extension cable 12 Pin
	34 0384	Flexkabel	Extension cable 30 Pin
	34 0293	Flexkabel	Flat cable 18 Pin
	34 0371	Flexkabel	Flat cable 18 Pin
	34 0325	Flexkabel	Flat cable 6 Pin
	340370	Flexkabel	Flat cable 7 Pin
	340326	Flexkabel	Flat cable 9 Pin

