



BOSCH

V344-WMV3440II/01-I1
V344-WMV3440II/02-I2
V344-WMV3440II/03-I3

WASCHGERÄTE
Waschvollautomaten

Ident-Nummern-Konstante
3740

Aufstellanweisung

51 4257

(I)

Gebrauchsanweisung

51 4258

(I)


Programmtabelle

51 4261

(I)

1) 02 5334

2) einschl. 05 4644




Ident-Nummern-Konstante
3740

1) 04 5561

2) 01 4687

3) 02 8437


4) 02 5345



**BOSCH**

V344-WMV3440II/01-I1
V344-WMV3440II/02-I2
V344-WMV3440II/03-I3

WASCHGERÄTE
Waschvollautomaten



Ident.-Nummern-Konstante
3740

1) 11 3216

2) 04 2309

3) 02 5350

4) 05 7022

**BOSCH**

V344-WMV3440II/01-I1
V344-WMV3440II/02-I2
V344-WMV3440II/03-I3

WASCHGERÄTE
Waschvollautomaten

Ident-Nummern-Konstante
3740

