


**BOSCH**

HMG8600/02-D1, braun
HMG8600BB/02-B2, braun
HMG8620/02-D2, weiss
HMG8620/03-D3, weiss

HMG8620BB/02-B1, weiss
HMG8620FF/02-F1, weiss
HMG8620NL/02-NL1, weiss
HMG8620NL/03-NL2, weiss

HERDE
Mikrowellenherde



Ident – Nummern – Konstante
3740

Gebrauchsanweisung

51 4191

(D, F, GB, I, NL)

Kurzanweisung

51 4193

(D)

Kochbuch

51 4192

(D)

51 4478

(NL)

Zubehör:

Einbaurahmen

HMZ 8000

D1, B2

HMZ 8020

D2, B1, F1, NL1, D3, NL2

kratzfeste Abdeckung

HMZ 8700

D1, B2

HMZ 8720

D2, B1, F1, NL1, D3, NL2

Alu-Backblech

HMZ 19 BB

Glaspfanne

HMZ 10 GP

Glasbräter

HMZ 21 GB

**BOSCH**


HMG8600/02-D1, braun
 HMG8600BB/02-B2, braun
 HMG8620/02-D2, weiss
 HMG8620/03-D3, weiss

HMG8620BB/02-B1, weiss
 HMG8620FF/02-F1, weiss
 HMG8620NL/02-NL1, weiss
 HMG8620NL/03-NL2, weiss

HERDE
 Mikrowellenherde

Ident – Nummern – Konstante
 3740

- 1) 03 0671
 2) 03 0813
 Arretierstift




**BOSCH**

HMG8600/02-D1, braun
 HMG8600BB/02-B2, braun
 HMG8620/02-D2, weiss
 HMG8620/03-D3, weiss

HMG8620BB/02-B1, weiss
 HMG8620FF/02-F1, weiss
 HMG8620NL/02-NL1, weiss
 HMG8620NL/03-NL2, weiss

HERDE
 Mikrowellenherde



Ident - Nummern - Konstante
 3740

- 1) 11 4538
Backblech
- 2) 11 4539
- 3) 11 4537
Glasschale
- 02 8732
Anschlag-Backblech
- 4) 03 0698
D1, B2
03 0688
D2, B1, F1, NL1, D3, NL2

**BOSCH**

HMG8600/02-D1, braun
 HMG8600BB/02-B2, braun
 HMG8620/02-D2, weiss
 HMG8620/03-D3, weiss

HMG8620BB/02-B1, weiss
 HMG8620FF/02-F1, weiss
 HMG8620NL/02-NL1, weiss
 HMG8620NL/03-NL2, weiss

HERDE
 Mikrowellenherde

Ident – Nummern – Konstante
 3740

