


Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		DRUCKSCHRIFTEN	
	53 1288	Gebrauchsanweisung D/I	Operating instructions
	53 1287	GB/DK	
	53 1286	F/E/NL/S	
	53 5648	Service Manual	Service manual
	53 5613	DL-Mechanik	
	53 5649	Schaltpläne und Platinen	Schematic diagram
		ZUBEHÖR	
	78 3177	AC Adaptor	FZ 157 G4
	75 1529	AC-Verbindungskabel	AC-cord
	79 4021	Akku 4,8V/1Ah	FZ 168 G4
	75 8918	Akku 4,8V/2,4Ah	FZ 169 G4
	79 5388	AV-Verbindungskabel	AV-cable, Chinch
	79 4612	Chinch-Scart Adapter	Chinch-scart adaptor
	79 4240	DC-Verbindungskabel	DC-output cable
	73 8076	S-Verbindungskabel	S-cable
	73 8884	Trageband	Shoulderstrap
	75 7000	VHS-C Cassettenadapter	FZ 163 G4

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		FUNKTIONSEINHEITEN	
	75 9908	Grundplatine, Camera	camera main P.C.B.
	79 6568	Sucher	E.V.F. P.C.B.
	79 6721	Linse, flex	lens, flex P.C.B.
	75 9910	Mikrophon	mic P.C.B.
	79 6567	AV – Buchsen	AV Jack P.C.B.
	79 6565	Eject	eject P.C.B.
	79 5488	Start – Stop	S/S P.C.B.
	79 6566	Manual Focus	front operation P.C.B.
		DIVERSE BAUTEILE	
	79 3347	Photo Sensor	photo sensor
J1501	79 3339	AV–Buchsenplatte	AV jack plate
J1601	79 6731	Batterieanschluß	battery connector
P1601	79 6732	DC–Buchse	DC–jack
VR501	79 3964	Focus–Regler	100 K
Z1601	79 3841	Lithiumzelle, VL2330/1HF	lithium battery



Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC201	79 5474	MN5224	
IC202	79 6555	MN31121SA	
IC203	79 6559	NN2035FAQ	
IC205	73 8278	AN1358S	
IC301	79 6552	F432512APZ	
IC302	79 5048	M62366GP	
IC303	79 6010	TC7W74FU	
IC308	79 6655	TC7S04FU	
IC701	79 6561	TB6526F	
IC702	79 6561	TB6526F	
IC706	79 6558	NJM2115VA	
IC710	79 6554	MN1882421M7P	
IC711	79 5059	TA75W01FU	
IC751	79 5480	TA75S393F	
IC801	79 4406	AN2516S	
IC1001	79 3803	BA9706K	
IC2001	79 5481	TB6518F	
IC2002	79 0798	UN224	
IC2003	79 0798	UN224	
IC3001	79 6553	HA118401F	
IC4001	79 5467	BA7758FS	
IC5001	79 5465	AN3355FHP	
IC5501	79 6557	MSM7470–73MS	
IC6001	79 6556	MN6755486M7R	
IC6002	79 5472	MM1273XFF	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
			
IC6003	79 6549	BU6194FV	
IC6004	79 6656	S29355	
IC6005	79 3089	BA6289F	
IC6006	79 4415	TA75W393FU	
IC6007	79 0770	TC4W53F	
IC6008	79 0771	TC7W04F	
IC6009	79 5321	SC7S08F	
IC6012	79 0770	TC4W53F	
			
S501	79 6722		
S6702	79 5616		
SW511	79 5617		
			
X301	79 3345	25,75 MHz	
X701	79 6724		
X5501	79 6723		
X6001	79 6148	1,6 MHz	
X6002	79 4671	32,768 MHz	

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
T801 T1001 T1002 T4001	79 6726	 Zeilentrafo	
	79 5619	Netzteil	
	79 4427	Netzteil	
	79 6725	Löschoscillator	
		MESSWERKZEUGE	
	34 0217	Conv. Fliter	C2
	34 0216	Conv. Fliter	C12
	34 0290	EVR Abgleichcomputer	EVR Fixture
	34 0214	H-Position Abgleich	H-Position adjustment
	79 6727	ROM 32	ROM 32
	34 0260	VHS-C Abgleichkassette	VHS-C Alignment Tape

Pos. Item Pos.	Ident-Nr. Ident-No N°d'ident	Bezeichnung	Designation Désignation
		ADAPTERKABEL	
	34 0189	EVR Verbindungskabel, 5 Pin	
	34 0199	Messadapter, 24 Pin	
	34 0291	24 Pin	
	34 0293	17 Pin	
	34 0368	12 Pin	
	34 0393	9 Pin	
	34 0394	6 Pin	
	34 0411	7 Pin	
	34 0413	28 Pin	
	34 0412	7 Pin	
	34 0475	18 Pin	
	34 0476	Flexkabel	
	34 0477	12 Pin	
	34 0478	9 Pin	
	34 0479	18 Pin	
	34 0480	18 Pin	
	34 0481	6 Pin	

