




Gebrauchsanweisung  
52 9022 (fr)

Aufstellanweisung  
52 2698 (fr)


Programmtabelle  
52 9023 (fr)

1) Blende kompl.  
36 2612 (fr)

Zubehör:


Bodenbefestigung  
WX9756

Entkalker  
46 0038



1) 2 x pro Gerät





- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
- 8) 16 5978

