






Gebrauchsanweisung
51 4331
(D,GB,F,I,NL,DK,N,
S,SF,E,P)
Montageanleitung
51 4009
(D,GB,F,I,NL,DK,N,
S,SF,E,P)
Schraubensatz
08 4136

Zubehör:

Dekorrahmen
Z4110A1, Alu
Z4110W1, weiß

1) 09 4859
2) 15 0719





	V01,V02	V03,V04	V05
Pos.	Matsushita	Danfoss	Goldstar
	SD 65 E	TLES 7 K	ND69NAEM
1	14 1316	14 1903	14 1999
2			
3	15 3306	15 1055	17 0743
4			
5	15 3865	15 0760	17 0745
6	15 3303	15 1072	17 0744
7			
8	27 0291	27 1372	27 0291
9	05 0166	05 0166	05 0166
10			
11	26 1981	08 4744	26 9660
12	05 6008	05 6008	05 6008

TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Matsushita	Danfoss	Goldstar
Typ/Type		SD 65 E	TLES 7 K	ND69NAEM
Förderleistung/Delivery/Débit	l/h	1170	1168	1242
Anlaufstrom/Starting current/Cour de démarrage	A		4,5	
Widerstand/Resistance/Résistance	Ha/main/prin. Ω		18,9	
	Hi/aux Ω		15,3	
Temp.-Regler/Thermostat				
Typ/Type				
Reglerstellung/Position				
Schaltwerte/Switching values/	„ein“ $^{\circ}\text{C}$			
Valeurs de commutation	„aus“			
(„abtauen“ od.)	„alarm“			
Füllmenge/Fill.quantity/Charge	R600a g			
Anschlußwert/Conn.load/Puiss. connectée	W	110	78	
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			
Schaltuhr/Timer/Minuterie de contact				
Widerstand/Resistance/Résistance	Ω			
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			