

Electrolux

SPARE PARTS LIST
Water Dispenser
5605

Item	PNC	ELC	Brand	Model	Market
A	956002412	00	Electrolux	EQAXF01BXWP	PHH


SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.

		Water Dispenser	
Electrolux Thailand Co.,Ltd. 1910 Electrolux Building New Petchburi Rd. Bangkok Huaykwang Bangkok , 10310 Tel : +662 725 9000			
Publication-No. 180702			

Model :
EQAXF01BXWP



Pos.	Part No.	Description
1	12163000A14091	front panel
2	12163000A14088	Plastic decoration of water mouth
3	12163000A14072	water mouth
4	12163000A14075	Front panel decoration
5	12163000A14073	drip tray cover
6	12163000010363	drip tray
7	12263000A02464	right panel
8	12163000A14080	door components
9	12963000000036	pin
10	12163000008044	base plate assembly
11	12163000001624	telescope suction tube
12	12263000000176	Support plate
13	11101010009735	Compressor
14	12963000000062	Compressor clamp
15	12963000000012	Process pipe
16	12663000A00222	Composite pipe
17	12263000A02565	ventilation silicon tube
17.1	17463100000010	Cooling temperature sensor
17.2	12963000000095	Cold tank plate
17.3	12463000A00081	Cold tank insulation foam
17.4	12263000000023	Cold tank
17.5	12163000002042	Protection loop
18	12663000002962	Outflow tube of water mouth
19	12163000001918	Cold water faucet
19.1	12663000A00641	Cold water outflow tube
20	12663000A00642	Normal water outflow tube assembly
21	12163000001918	Cold water faucet
21.1	12663000A00571	Hot water outflow tube
22	12163000005721	push rod
23	12163000010370	Light cover
24	17163000A00604	display board
25	12163000005181	Key pad

Pos.	Part No.	Description
26	12963000A00461	spring
27	12163000004689	push rod
28	12163000010368	The keys
29	17463000000094	heating switch
30	17463000000076	cooling switch
31	12163000A14089	Top cover
32	12163000A13794	cold cover
33	12163000001825	Shunt plate
34	12163000001642	Back cover
35	12663000000396	Sealing ring
36	17163000000120	PCB board
37	12263000000224	PCB board cover
36+37	17163000000128	PCB board + PCB board cover
38	12963000000002	The condenser
39	12963000000016	Drying filter
40	12963000000074	piece
41	17463000A00401	power cord
42	17463000000131	Heating thermostat
43	17463000A01142	Overheating thermostat
44	12163000002058	Fixing block of power cord
45	17463000A00861	hot tank
46	12163000001621	Waste water cover
47	12163000002134	Nut wastewater
48	12663000000343	drainpipe
49	12263000A02461	left panel
50	12163200000462	plug
51	17463000A00181	pump
52	12163000002063	Door switch box
53	17463000000108	door switch

Model :
EQAXF01BXWP

Wiring diagram

