



Electrolux

SPARE PARTS LIST

Electric Instant Water Heater

5610

Item	PNC	ELC	Brand	Model	Market
A	956002427	00	Electrolux	EWE381KX-DWG6	THE


SAFETY WARNING

Always turn off and unplug THE machine before detaching any parts.

When servicing machines, do not remove ANY detachable parts while THE machine is powered.

THE reason is internal faults may cause shorts to components that are normally at low voltage presenting a shock hazard.

		Electric Instant Water Heater	
Electrolux Thailand Co.,Ltd. 1910 Electrolux Building New Petchburi Rd. Bangkapi Huaykwang Bangkok , 10310 Tel : +662 725 9000		Publication-No. 190816	




Item	PNC	ELC	Brand	Model	Market
A	956002427	00	Electrolux	EWE381KX-DWG6	THE

Pos.	Part No.	Description
E1	5TBK--001CM---B0	TERMINAL BLOCK (TLB--300W) PA-12
E2	5PCAME178ELCA-J1	MICRO CONTROLLER BOARD-ASSY ME III NP (EWE) DPDT MEIDU (FULL SET) (NEW FARA) (REV1)
E3	5THMCM026CM---C0	ATT BIMETAL THERMOSTAT(AL)S102CT 2CH16- RV1-DD-MR, 55C AUTO, 90C MANUAL
E4	5RSACM026CM---A0	REED SWITCH ASSY (COMMON) PS-0135-601 (FOR ALLURE II, AURORA, SLIM, MR7)
E5	6HTKHT144CM-NAA0	HEATER ELEMENT-TANK 3855-ASY 240V-3.6KW NATURAL - VBC
E6	4FSACM005CM---F0	FLIP START MAGNET ASS'Y (COMMON)
EA	5TRA--001CM-QCB0	TRIAC (TG25C60) ASSY
PA	1PCAE3001EL-WHC0	PLASTIC COVER - ALLURE III (NP) (ELECTROLUX) HIGH GLOSS WHITE
P2	1PKEE2009EL-BLC0	PLASTIC KNOB- ELCB ALLURE II SBL SKY BLUE INJECTION PER SET
P3	1LDPRF002EL-TPF0	LED PLUG TRANSPARENT- MR7EX
P4	1FPLE3003EL-BLC0	FACE PANEL- ALLURE III (EWE) SKY BLUE
PB	1PTKE3001EL-GYC0	PLASTIC KNOB-TEMPERATURE ASSY ALLURE III GREY
P8	3VKICM006CM-WHC0	PLASTIC KNOB-VR-KNOB INSERT-U2 COMMON WHITE
P9	3IPLME004CM---C0	INLET PIPE LOWER - ME
P10	3IPUME007CM---C0	INLET PIPE UPPER LONG - ME
P11	3ELCME006CM-NTC0	ELBOW CONNECTOR COVER (ME III) NATURAL
P12	3ELPME009CM-NTC0	ELBOW CONNECTOR PIPE (ME III) NATURAL (SHORT)
P13	3OTPME005CM-NTC0	OUTLET PLASTIC PIPE (ME) NATURAL
P14	3HBAME070CM-WHC0	PLASTIC BASE ASSY ALLURE III NP WHITE
P15	3GMTCM003CM-BK-0	GROMMET (BLACK) 23(OD)x6(ID)x8(H)mm (COMMON) EXCEPT - US/ TS1/ OB
A1	2ACSMK093EL---A0	SHOWER HEAD SET CW ACCESSORIES WALL BRACKET RP-14 MK BOX
A2	2ACHCM034CM----0	SHOWER HEAD R-423 ANTIBACTERIAL R (EWE)
A3	2ACPCM002EL----0	1.5M PVC HOSE + PVC HOSE WASHER EWE
A4	2ACVCM018CM-WHC2	FILTER VALVE 3 IN 1-WH (P) DOME (PLASTIC SHAFT)DOME MESH FILTER-RDL (REV2)

Item	PNC	ELC	Brand	Model	Market
A	956002427	00	Electrolux	EWE381KX-DWG6	THE

Pos.	Part No.	Description
	1SPRE2018CM---F0	SPRING-E2 (0.70T X ID9.4 X14L)
	7CLPCM004CM---A0	E-RINGS ETW - 2.5 NP
	5WIRME216EL---A0	WIRE HARNESS-ME III NP DPDT (2.4,3.5,3.6 KW) - ALLURE III/AURORAII
	7ORGCM002CM---A0	O.RING ID9.0MM X CS2MM (COMMON)
	7ORGCM003CM---A0	O.RING ID16MM X CS2MM (COMMON)
	7ORGCM026CM-BKA0	O-RING ID33MM X CS2.0MM NBR 70SHORE (BLACK) DISOREQ
	7ORGCM031CM-BKA0	O-RING ID3.0MM X CS1.5MM 70SHORE (BLACK) DISOREQ
	7ORGCM032CM-BKA0	O-RING ID17.12MM X CS2.62MM NBR 70SHORE (BLACK) DISOREQ
	7CLPCM002CM----0	PIPE CLIP 17.5
	7CLPCM001CM----0	PIPE CLIP
	3GMTCM003CM-BK-0	GROMMET (BLACK) 23(OD)x6(ID)x8(H)mm (COMMON) EXCEPT - US/ TS1/ OB

WIRING DIAGRAM -WITH ELCB, NO PUMP DPDT MODEL



SAFETY WARNING

Always turn off and unplug THE machine before detaching any parts.

When servicing machines, do not remove ANY detachable parts while THE machine is powered. THE reason is internal faults may cause shorts to components that are normally at low voltage presenting a shock hazard.