




|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 24133     | 24133     |
| SR134A1   | SR134ATF1 |
| 24133     | 28619     |
| WR134A1   |           |
| 24133     |           |

|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 32513     | 33906     |
| SR134A1   | SR134ATF1 |
| 34090     | 33909     |
| WR134A1   |           |
| 34090     |           |

|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 19866     | 19864     |
| SR134A1   | SR134ATF1 |
| 19864     | 19864     |
| WR134A1   |           |
| 19869     |           |

|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 24309     | 19862     |
| SR134A1   | SR134ATF1 |
| 19862     | 19862     |
| WR134A1   |           |
| 19862     |           |

|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 19865     | 19863     |
| SR134A1   | SR134ATF1 |
| 19863     | 19863     |
| WR134A1   |           |
| 19868     |           |

|           |           |
|-----------|-----------|
| SR134AEB1 | SR134ANE1 |
| 23701     | 23698     |
| SR134A1   | SR134ATF1 |
| 23702     | 24402     |
| WR134A1   |           |
| 23702     |           |

|     |      | GAS METANO |      | GAS LIQUIDO |
|-----|------|------------|------|-------------|
| URP | 1.45 | 13985      | 0.95 | 17233       |
| AUS | 0.76 | 6896       | 0.48 | 6881        |
| SRP | 0.93 | 6895       | 0.62 | 6880        |

## SR134ATF1

## Varianti-Changes-Modifications-Veränderung-Variantes

| Cod.Vecchio-Old Code-Vieux Code-Alte Teilnr.-Cod.Vejio                                                                          | Cod.Nuovo-New Code-Nouv.Code-Neue Teilnr.-Codigo Nuevo                                                                             | Data |
|---------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|------|
| <b>018930591</b><br>TRAVERSA ACCENSIONE S134AS1<br>IGNITION CROSSPIECE<br>TRAVERSE D'ALLUMAGE<br>ZUND. KREUZB.                  | <b>698930665</b><br>GRUPPO TRAVERSA ACCENSIONE S134AS1<br>ASS.IGNITION CROSSPIECE<br>ENS.TRAVERSE D'ALLUMAGE<br>ZUNDUNG QUERTRAGER | 0//0 |
| <b>038290262</b><br>STAFFA FISS AL TOP S564<br>AT THE TOP FIX. FLASK<br>ETRIER FIX. TAQUE<br>BUGEL                              | <b>698290263</b><br>GRUPPO STAFFA FISSAGGIO TOP S564<br>FIXING TOP BRACKET<br>ETRIER DE FIXAGE<br>BEFESTIGUNGSKLAMMER              | 0//0 |
| <b>305611980</b><br>PIANALE 4 FUOCHI TERRA DI FRANCIA SR134ATF1<br>4FIRE WORKING HOB (TF)<br>TAQUE 4F TERRE DE FRANCE<br>MULDE  | <b>305612495</b><br>PIANALE 4 FUOCHI TERRA DI FRANCIA SR134ATF1                                                                    | 0//0 |
| <b>618971301</b><br>TUBO RAMPA ZINCATO CL4G<br>RAMP HOSE<br>TUYAU RAMPE<br>BRENN.GR. ROEHRE                                     | <b>698971656</b><br>GRUPPO TUBO RAMPA S134A1<br>ASS.RAMP HOSE<br>ENS.TUYAU RAMPE<br>RAMPE SCHLAUCH GRUPPE                          | 0//0 |
| <b>810020072</b><br>ACCENDITORE V220-240 S134AS-E<br>IGNITOR<br>ALLUMERE<br>ZUNDUNG                                             | <b>810020089</b><br>ACCENDITORE 4 FUOCHI RAPIDO SM34AX1<br>IGNITOR 4F RPD<br>ALLUMEUR 4F RPD<br>ANZUENDER 4F RPD                   | 0//0 |
| <b>810930053</b><br>CANDELETTA ACCENSIONE MM 550 AP31<br>SPARK PLUG L=550MM<br>BOUGIE CABLE MM550<br>ZUNDKERZE                  | <b>810930078</b><br>CANDELETTA ACCENSIONE MM.550 A1.1<br>SPARK PLUG MM. 550<br>BOUGIE ALLUM. MM. 550<br>ZUENDKERZE MM. 550         | 0//0 |
| <b>810930058</b><br>CANDELETTA ACCENSIONE MM 550 SRV564<br>SPARK PLUG MM 550<br>BOUGIE ALLUM. 550 MM<br>ZUNDKERZE               | <b>810930072</b><br>CANDELETTA ACCENSIONE MM 550 SRV596/1<br>SPARK-PLUG 550MM<br>BOUGIE D'ALLUMAGE 550MM<br>ZUENDKERZE 550MM       | 0//0 |
| <b>870650141</b><br>BRUCIATORE ULTRARAPIDO SR134A-E<br>U/RAPID BURNER<br>BRULEUR RAPIDE<br>BRENNER                              | <b>870650142</b><br>BRUCIATORE ULTRARAPIDO SR134AS-E<br>U/RAPID BURNER<br>BRULEUR ULTRA-RAPIDE<br>ULTRASCHNELL BRENNER             | 0//0 |
| <b>870650159</b><br>BRUCIATORE SEMIRAPIDO MONOPEZZO S134ASE<br>SEMI-RAPID BURNER<br>BRULEUR SEMI-RAPIDE<br>BRENNER- HALBSCHNELL | <b>870650223</b><br>BRUCIATORE SEMIRAPIDO MONOPEZZO SRV596X1<br>S/RAPID BURNER<br>BRULEUR SRP<br>HALBSCHNELL BRENNER               | 0//0 |

**SR134ATF1**

|                  |                                                                                             |                  |                                                                                                     |             |
|------------------|---------------------------------------------------------------------------------------------|------------------|-----------------------------------------------------------------------------------------------------|-------------|
| <b>870650160</b> | BRUCIATORE AUSILIARIO MONOPEZZO<br>S134ASE<br>AUXIL. BURNER<br>BRULEUR AUX.<br>HILFSBRENNER | <b>870650222</b> | BRUCIATORE AUSILIARIO MONOPEZZO<br>SRV596X1<br>AUXILIARY BURNER<br>BRULEUR AUX.<br>HILFSBRENNER     | <b>0//0</b> |
| <b>899371154</b> | VITE 5,9SPX19 TS INX TORX<br>S/S TORX BURNERS SCREW<br>VIS TORX BRUL.INOX<br>SCHRAUBE       | <b>899371334</b> | VITE AUTOFILETTANTE 5,9X19 INX TSPE<br>SCREW FOR BURNERS<br>VIS POUR BRULEURS<br>SCHRAUBE F.BRENNER | <b>0//0</b> |