



Electrolux

SPARE PARTS LIST

Coffee Drip Machine

3480

Item	PNC	ELC	Brand	Model	Market
A	900273417	00	Electrolux	ECM1303W	IDH
A	900273419	00	Electrolux	ECM1303W	MYH/SGH
A	900273411	00	Electrolux	ECM1303W	THE
A	900273413	00	Electrolux	ECM1303W	VNE
A	900273415	00	Electrolux	ECM1303W	PHH

SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.

		Small Appliance Coffee Drip Machine	
Electrolux SEA Pte.,Ltd. APAC	Publication-No. 140626		

Model	PNC
ECM1303W	900273417
ECM1303W	900273419
ECM1303W	900273411
ECM1303W	900273413
ECM1303W	900273415

Ex. View Drawing Accessories



POS.	Supplier No.	Part Name	Description
1	SP428501W	White Carafe assembly	Carafe + Carafe handle + Handle cover + Carafe cover + Carafe fix ring + Carafe block + screw
2	SP428502	Funnel assembly	Funnel + Anti drip calve
3	SP428504	Filter	Filter
4	SP428503	Silicon foot	Silicon foot