



Mat. - Nr. - Konstante
3740

Gebrauchsanweisung
59 2794

(ES,GB,FR,PT)

1) 17 1312

2) 42 4340

3) 43 8723

4) 49 5511

V01

49 7503

V02

5) 16 5552

6) 36 9906

7) 42 8184

8) 42 4825

9) 44 3698

10) 36 9820


11) 43 7164

12) 36 6905

V01

44 4818


V02



Mat. – Nr. – Konstante
3740

1) 42 6286

2) 16 5557



Pos.	Danfoss		
	NLE13KK3		
1	14 3864		
2	18 1014		
3	35 4158		
4	16 3427		
5	49 4671		
6	17 1318		
7	17 1519		
8	42 0376		
9	16 5570		
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	Danfoss NLE13KK3 6.4 12.9 18		
Temp.Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actua kapama degerleri Valeurs de commutation/Termostat degeri (..abtaven' od)	..ein/acma °C ..aus"/kapama ..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı	R600	g	42
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ohm W		
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ohm		
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ohm V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz