





Libro de instrucciones  
51 7464  
(E,P,GB,,F,NL,GR)


Instrucciones R600a  
51 9240  
(D,GB,F,I,NL,DK,N,  
S,SF,P,GR,E,TR)

Instrucciones de montaje  
51 9729  
(D,GB,F,I,NL,E,P,GR)

Anexo ind. temperatura  
52 0758  
(D,GB,F,I,NL,E,SF,S,N,  
DK,P,GR)

1) 06 7746  
2) 03 3055





| Pos. | *****              |                    |  |  |
|------|--------------------|--------------------|--|--|
|      | Aspera<br>BMP1084Y | Aspera<br>BMP1110Y |  |  |
| 1    | 14 1723            | 14 1605            |  |  |
| 2    | 15 4315            | 15 4315            |  |  |
| 3    | 16 7769            | 16 5230            |  |  |
| 4    |                    |                    |  |  |
| 5    |                    |                    |  |  |
| 6    | 26 4123            |                    |  |  |
| 7    | 05 0166            | 05 0166            |  |  |
| 8    | 28 0162            | 28 0162            |  |  |
| 9    |                    |                    |  |  |
| 10   |                    |                    |  |  |
| 11   |                    |                    |  |  |
| 12   |                    |                    |  |  |
| 13   |                    |                    |  |  |

| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS                                                                                                                                                                            |                                                     |                                                                        |    |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|------------------------------------------------------------------------|----|--|
| *****                                                                                                                                                                                                                                        |                                                     |                                                                        |    |  |
| Verdichter/Compressor/Compresseur/Compresor<br>Typ/Type/Tipo<br>Förderleistung/Delivery/Debit/Aspiración l/h<br>Anlaufstrom/Starting current/Cour.démarrage/Int.arranq. A<br>Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm<br>Hi/aux. | Aspera<br>BMP1084Y                                  | Aspera<br>BMP1110Y                                                     |    |  |
|                                                                                                                                                                                                                                              | 3,60                                                |                                                                        |    |  |
|                                                                                                                                                                                                                                              | 29,60                                               | 24,70                                                                  |    |  |
|                                                                                                                                                                                                                                              | 38,50                                               | 37,65                                                                  |    |  |
| Temp.Reyler/Thermostat/Termostato<br>Typ/Type/Tipo<br>Reglerstellung/Position/Conexión<br>Schaltwerte/Switching values/ ..ein/conex.°C<br>Valeurs de commutation/Desconex. ..aus"/descon.<br>(..abtaven' od) ..alarm"                        | Ranco<br>K59-L6045<br>MIN. MAX.<br>+6°<br>-14° -28° | Ranco<br>K54-L1941<br>MIN. MAX.<br>-14° -22°<br>-20° -28°<br>-10° -18° |    |  |
| Füllmenge/Fill. quantity/Charge/Carga R600a                                                                                                                                                                                                  | g                                                   | *                                                                      | *  |  |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc.                                                                                                                                                                                             | W                                                   | 71                                                                     | 86 |  |
| Heizung/Heater/Chauflage/Resistenc.descong.<br>Widerstand/Resistance/Resistencia<br>Leistung/Power/Puissance/Potencia                                                                                                                        | Ohm<br>W                                            |                                                                        |    |  |
| Ventilador/Blower/Ventilateur/Ventilador<br>Widerstand/Resistance/Resistencia                                                                                                                                                                | Ohm                                                 |                                                                        |    |  |
| Magnetventil/Magnetic valve/Electrovanne/Electrovalvula<br>Widerstand/Resistance/Resistencia<br>Spannung/Voltage/Tension/Tensión                                                                                                             | Ohm<br>V                                            |                                                                        |    |  |
| Temp.Reyler/Thermostat/Termostato ambiente para<br>ventilador refrigerador                                                                                                                                                                   |                                                     |                                                                        |    |  |

\* Siehe Typenschild / See identification plate / Voir plaque de caractéristiques / Ver plaqueta de caracteristicas