






Kullanma kilavuzu
52 7025
(DE,GB,TR)

- 1) 16 5552
- 2) 36 0819
- 3) 36 0847
- 4) 17 1308
- 5) 18 2029



- 1) 48 0523
- 2) 48 0522
- 3) 26 9013
- 4) 16 6484
- 5) 16 5557
- 6) 26 6470
- 7) 26 7020
- 8) 35 4314
- 9) 36 0843
- 10) 36 0839
- 11) 36 0841
- 12) 17 1319



Pos.	Danfoss		
	NL9FT		
1	14 1811		
2	16 5570		
3	35 4158		
4	16 3427		
5	26 5327		
6	17 1318		
7	17 1519		
8	17 2776		
9	18 1014		
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER

Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	A Ohm	Danfoss NL9FT 12.8/8.1 8.9 12		
Temp.Reyler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actua kapama degerleri Valeurs de commutation/Termostat degeri (..abtafen' od)	Elektronisch ..ein/acma °C ..aus"/kapama ..alarm'			
Füllmenge/Fill. quantity/ Dolum miktarı	R134a	g	*	
Anschlusswert/Comm. load/Giris gucu	W			
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ohm W	Verdampfer 190	Ablaufrinne 67	
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ohm	Verdampfer		
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ohm V			
Temp.Reyler/Thermostat/Termostat				

* Siehe Typenschild/Mamul etiketine bakınız