



Mat. – Nr. – Konstante
3740


Gebrauchsanweisung
59 1585
(TR)

- 1) 17 1312
- 2) 42 4340
- 3) 43 8728
- 4) 49 4164
- V01
- 49 7503
- V02,V03,V04
- 5) 16 5552
- 6) 43 5739
- 7) 41 8128
- 8) 49 1346
- 9) 43 5707
- 10)43 5738
- V01
- 44 6179
- V02,V03,V04
- 11)42 4398



Mat. – Nr. – Konstante
3740

- 1) 49 0670
2) 06 0083
3) 49 1343
4) 49 1361
5) 44 0441
6) 49 0669
7) 18 8194
8) 18 8188
9) 16 5557
10) 17 1319
V01,V02
60 2197
V03,V04



	V01	V02	V03,V04
Pos.	Danfoss NLE15KTK2		
1	14 2207		
2	18 1014		
3	35 4583		
4	16 3427		
5	49 4671		
6	17 1318		
7	17 1519		
8	42 6296	16 5570	16 5570
9	17 4093		41 6399
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör Typ/Type/Tip Förderleistung/Delivery/Verim/h Anlaufstrom/Starting current/Giris akimi Widerstand/Resistance/Rezistans Ha/ Hi/aux.	Danfoss NLE15KTK2 8 A Ω		
Temp. Regler/Thermostat/Termostat Typ/Type/Tip Reglerstellung/Position/Termostat pozisyonu Schaltwerte/Actma kapama degerleri Valeurs de commutation/Termostat degeri (...abtaven' od)	Elektronisch ..ein/acma °C ..aus"/kapama ..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı	R600 g	65	
Anschlusswert/Comm. load/Giris gucu	W		
Heizung/Heater/Rezistans Widerstand/Resistance/Direnc Leistung/Power/Guc	Ω W		
Ventilador/Blower/Vantilatör Widerstand/Resistance/Rezistans	Ω		
Magnetventil/Magnetic valve/Manyetik valf Widerstand/Resistance/Rezistans Spannung/Voltage/Gerilim	Ω V		
Temp. Regler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız