






Libro de instrucciones
51 6294
(E, P, GB, F, NL, GR)





Pos.	KÜHLGERATE
	UNIDAD HERMETICA
	GL80AA
1	14 1339
2	15 4818
3	
4	
5	
6	
7	
8	28 9409
9	06 4260
10	
11	09 6864

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo	U.HERMETICA GL80AA
Förderleistung/Delivery/Debit/Aspiración l/h	
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	11,5
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	11,6
Hi/aux.	20,8

Temp.Reyler/Thermostat/Termostato Typ/Type/Tipo	ATEA MANUAL
Reglerstellung/Position/Conexión	+5°
Schaltwerte/Switching values/ ..ein/conex. °C	-15°
Valeurs de commutation/Desconex. ..aus"/descon.	-32°
(..abtaven' od) ..alarm'	

Füllmenge/Fill. quantily/Charge/Carga R134a	g	155
---	---	-----

AnschluBwert/Comm. load/puiss. Connect./Potenc.	W	162
---	---	-----

Heizung/Heater/Chauflage/Resistenc.descong.		
Widerstand/Resistance/Resistencia	Ohm	3782
Leistung/Power/Puissance/Potencia	W	12,5

Ventilador/Blower/Ventilateur/Ventilador		
Widerstand/Resistance/Resistencia	Ohm	

Magnetventil/Magnetic valve/Electrovanne/Electrovalvula		
Widerstand/Resistance/Resistencia	Ohm	
Spannung/Volare/Tension/Tensión	V	

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador		
--	--	--