



Gebrauchsanweisung

51 4839

(D)

51 4961

(D,I,SF,N,S)

Aufstellanweisung

51 4750

(D,GB,F,I,NL,E)

Programmtabelle

51 4840

(D,GB)

1) 27 3934

Blende kompl.

2) 03 2288

3) 05 9694

4) 05 9344

Zubehör:
Bodenbefestigung

CZ 1106

Wäsche-Top

CZ 11330


Verlängerung


Zulaufschlauch 2,5 m

CZ 11350

Entkalker

46 0038





wahlweise

	SIEMENS 1BA675..	CESET MCA52/64.
a)	14 0579	14 1148
b)	09 2024	15 1614

