





Gebrauchsanweisung
51 9913
(D,I,E)
51 9914
(NL,F,GB)

Montage- und
Aufstellanweisung
51 9653
(D,NL,F,E,GB,I,SF,F,S,
N,DK,P)

Programmtabelle
 51 9801
 (D)
 51 9803
 (NL)
 51 9804
 (F)
 51 9805
 (GB)
 51 9806
 (I)
 51 9915
 (E)

1) Blende kompl.
29 7599
Blendeneinlage 2)
mitbestellen



Zubehör:

Höhenanpassung 91 cm:
WZ 10100

