




Mat. – Nr. – Konstante
3740

Gebrauchsanweisung
52 5771
(de,en,fr,it,nl,es,el,pt)

Montagehilfe
35 9286

Düsensätze:
FG 30mbar
17 4074
FG 50mbar
17 2265
EG-E 20mbar
17 3458
EG-LL 20/mbar
17 5731
EG-L 25mbar
17 5751
SG-G110 8mbar
17 3459
SG-G120 8mbar
17 4078