




Mat. – Nr. – Konstante

3740

Gebrauchsanweisung

58 7714 (de)

59 0336 (es)

Montageanweisung

58 6500

(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:

HZ331070

Backblech emailliert

HZ331010

Backblech Antihft

HZ332070

Universalpfanne


HZ332010

Universalpfanne


Antihft







Zubehör:
HZ9150
Glasbraeter
HZ6000
Metallbraeter
HZ333102
Profiauszug



1) 42 2707

