




51 5100
Gebrauchsanweisung
(D)

51 1936
Tips und Rezepte
(D)


51 0833
Bratzeit-Aut.-Scheibe
(D,GB,F,I,NL)

1) 05 3176
2) 02 1947
3) 02 9370
4) 01 8981
5) 05 1477
6) 08 3566


Zubehör:


Alu-Backblech
CZ 20170



Bratrost
CZ 20180




1) 02 2695









1) 09 5120
Set