


**BOSCH**

HMG8628NL/01–NL1, weiss
HMG8628NL/02–NL2, weiss

HERDE
Mikrowellenherde



Ident – Nummern – Konstante
3740

Gebrauchsanweisung

51 6082

(D,F,GB,I,NL)

NL1

51 6087

(D,F,GB,I,NL)

NL2

Tips und Rezepte

51 5859

(NL)

Einbauanweisung

51 3932

(D,GB,F,I,NL,N,S,SF,DK)

Aufkleber Programm-
tabelle

51 6344

(D,GB,F,I,E,N)

NL1

Zubehör:

Alu-Backblech

HMZ 19BB

Glaspfanne

HMZ 10GP

Glasbräter

HMZ 21GB




BOSCH

HMG8628NL/01–NL1, weiss
HMG8628NL/02–NL2, weiss

HERDE
Mikrowellenherde

Ident – Nummern – Konstante
3740


- 1) 03 0671
 - 2) 03 0813
- Arretierstift



**BOSCH**

HMG8628NL/01–NL1, weiss
HMG8628NL/02–NL2, weiss

HERDE
Mikrowellenherde




Ident – Nummern – Konstante
3740

- 1) 11 4538
Backblech
- 2) 11 4539
- 3) 11 4537
Glasschale
02 8732
Anschlag–Backblech
- 4) 03 0688
- 5) 23 2269
NL1,NL2
- 6) 09 2677
kompl.
- 7) 27 0323
- 8) 09 2862
NL1,NL2

**BOSCH**

HMG8628NL/01–NL1, weiss
HMG8628NL/02–NL2, weiss

HERDE
Mikrowellenherde



Ident – Nummern – Konstante
3740

- 1) 03 0678
- 2) 08 7477



BOSCH

HMG8628NL/01–NL1, weiss
HMG8628NL/02–NL2, weiss

HERDE
Mikrowellenherde

Ident – Nummern – Konstante
3740

