




Libro de instrucciones
51 7394
(E, P, GB, F, D)







Pos.	KÜHLGERÄTE
	ZEM
	GL80AA
1	14 1362
2	15 4818
3	
4	
5	
6	
7	
8	28 9409
9	05 0166
10	
11	09 6332

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo	ZEM GL80AA
Förderleistung/Delivery/Debit/Aspiración l/h	
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	11,5
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	11,6
Hi/aux.	21,2

Temp.Reyler/Thermostat/Termostato Typ/Type/Tipo	ATEA MANUAL
Reglerstellung/Position/Conexión	+5°
Schaltwerte/Switching values/ ..ein/conex. °C	-15°
Valeurs de commutation/Desconex. ..aus"/descon.	-32°
(..abtaven' od) ..alarm'	

Füllmenge/Fill. quantily/Charge/Carga R134a	g	160
---	---	-----

AnschluBwert/Comm. load/puiss. Connect./Potenc.	W	
---	---	--

Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia	Ohm	3782
Leistung/Power/Puissance/Potencia	W	12,5

Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Ohm	
---	-----	--

Magnetventil/Magnetic valve/Electrovanne/Electrovalvula Widerstand/Resistance/Resistencia	Ohm	
Spannung/Volare/Tension/Tensión	V	

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador		
--	--	--