





Gebrauchsanweisung
58 4357
(de,fr,nl,it)


Montageanleitung
52 3265
(de,fr,nl,it)

Zubehör:


Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
gekröpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X2
Universalpfanne u.
Bratrost
Z1230X2



1) 18 2645
V01
18 2652
V02
18 2656
V03



- 1) 17 2765
- 2) 17 2646
- 3) 18 2612
- V01
- 18 2427
- V02, V03
- 4) 18 2650
- V01
- 18 2654
- V02
- 18 2658
- V03
- 5) 36 1653
- V01
- 36 1657
- V02
- 36 1662
- V03



1) 15 4779