




Mat. – Nr. – Konstante
3740

Gebrauchsanweisung


58 8717 (de)
59 7326 (cs)
59 7327 (da)
59 7328 (el)
59 7329 (en)
59 7330 (es)
59 7331 (et)
59 7332 (fi)
59 7333 (fr)
59 7334 (hr)
59 7335 (hu)
59 7336 (it)
59 7337 (lt)
59 7338 (lv)
59 7339 (nl)
59 7340 (no)
59 7341 (pl)
59 7342 (pt)
59 7343 (ru)
59 7344 (sk)
59 7345 (sv)
59 7346 (tr)
59 7347 (uk)

Montageanweisung

58 8262
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)


1) 01 4254
2) 02 0943






Mat. – Nr. – Konstante
3740

Zubehoer:
HEZ341000
Backblech emailliert
HEZ341010
Backblech Antihalt
HEZ341670
Backblech (Auszug)
HEZ342000
Universalpfanne
HEZ342010
Universalpfanne
Antihalt
HEZ343000
Profipfanne
HEZ333001
Deckel f. Profipfanne
HEZ344000
Kombirost
HEZ324000
Einlegerost
HEZ325000
Grillblech 2-teilig
HEZ346000
Glaspfanne
HEZ6001
Backform
Auslaufsicher
HEZ317000
Pizaform
HMZ21GB
Glasbraeter
HEZ6000
Metallbraeter




Mat. – Nr. – Konstante
3740
1) 06 8492



Mat. – Nr. – Konstante
3740

- 1) 42 2755
- 2) 42 2747



Mat. – Nr. – Konstante
3740

