




Gebrauchsanweisung
(de,en,fr,nl,it,es)
52 3342

1) 16 7354

Düsensätze:

Flüssiggas 50mbar
17 1620

Flüssiggas 30mbar
16 7552

Erdgas E20mbar
16 7553

Erdgas LL, 20mbar
16 9538

Erdgas L, 25mbar
16 9553
(NL)

