




Gebrauchsanweisung
51 6762
(F)

Aufstellanweisung
51 4750
(D,GB,F,I,NL,E)
51 4934
(D,I,SF,N,S)

Programmtabelle
51 4835
(F)

1) 28 5695
Blende kompl.
2) 03 2288
3) 05 9694


Zubehör:


Bodenbefestigung
WX9756


Wäschetop
WZ10120/01


Verlängerung
Zulaufschlauch 2,5m
WZ10130/01

Entkalker
46 0038









28 8964

02 7780

45 0555
1,5m
45 0652
2,5m

