




Gebrauchsanweisung

51 6614
(NL, F, E, GB)
51 6615
(D, I, SF, N, S)

Aufstellanweisung

51 4750
(D, GB, F, I, NL, E)
51 4934
(D, I, SF, N, S)

Programmtabelle

51 4753
(GB, F, E, NL)
51 4754
(D, I, SF, N, S)

1) 28 5372
V01, V04
Blende kompl.
28 5691
V02, V03, V05
Blende kompl.

2) 03 2288

3) 05 9694


Zubehör:


Bodenbefestigung
WX9756

Wäschetop
WZ10120/01


Verlängerung
Zulaufschlauch 2,5m
WZ10130/01

Entkalker
46 0038





1) 28 5383
15 5272
Triac-Motorleistung



28 8964

