




Gebrauchs-/  
 Aufstellanweisung  
 58 4340 (de)  
 58 5293 (nl)

Programmtabelle  
 58 4341 (de)  
 58 5294 (nl)

1) Blende kompl.  
 43 2160 (de) V01  
 43 2162 (de) V02  
 43 2693 (nl) V03


Zubehör:


Bodenbefestigung  
 WX9756

Entkalker  
 46 0038

Verlängerung  
 Zulaufschlauch 2,5 m  
 WZ10130

1) 2 x pro Gerät





- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138  
kompl.
- 8) 16 5978
- 9) 16 7191
- 10) 41 8217

